
Getting Started Guide

Welcome to the NetFPGA-SUME getting started guide!

This guide is for new users. It covers:

- System Requirements.
- Downloading the code repository.
- Installation.
- Testing your board.
- What to do next!

Let's get started...

Section I: System Requirement

Operating Systems

In principle, any operating system that is supported by the Xilinx Vivado Design Suite should work for composing and synthesizing the IP in the code base. However, please note that the NetFPGA team develops strictly on Linux. While hardware composition and synthesis can be done on any platform which runs the Xilinx tools, software components of the NetFPGA-SUME platform have been and will continue to be developed initially for Linux. The Linux Operating System that NetFPGA team is using for development is Ubuntu 14.04 (x86_64), and releases are tested only on this operating system. Special care is needed for installing the driver on Linux Operating Systems. The [Reference Operating System](#) page will provide you instructions about how to set up the development system.

Xilinx Tools

To do any development you will need the Xilinx Vivado Design Suite. Please note that (until the SUME project is stable) the NetFPGA team strives to always use the latest version of the tools, and we strongly advise all other developers to do the same. At the time of writing, the version is Xilinx Vivado Design Suite 2014.4.

Xilinx IP Core License

In order to build bitstreams, you must have a valid license for Xilinx 10G MAC.

Network Cables

The NetFPGA-SUME board has four SFP+ connectors for 10Gb Ethernet. The IP core supports 10GBASE-SR/LR transceivers. The transceiver we used in development is AVAGO AFBR-709SMZ with Multimode OM3 10Gb Fibre.

Host Motherboard

The NetFPGA-SUME board works both standalone and inside a host. If you intend to use the NetFPGA-SUME board in a host, you need to make sure that the motherboard supports PCI Express Gen3 x8 configuration. It is recommended to have an up-to-date firmware on your motherboard. For some motherboards, you may need to set the PCI Express configuration to Gen3 in the BIOS configuration manually.

Other Stuff

You need a micro-USB cable to access the JTAG chain or serial port of the reference design. You can also use a Xilinx Platform Programming cable to access the JTAG chain on board.

Section II: Register to the Beta Program

Prior to accessing code, we need you to register [here](#). We do this to understand who is using NetFPGA-SUME, so please give as complete answers as you can. The better usage we can show, the more support we can motivate our sponsors to provide. Feel free to explore the wiki, it is publicly readable.

Continue on from here once you have registered.

Download the Code Base

The code base for NetFPGA-SUME board is available as a git repository hosted on GitHub.

After you have gained access to the repository, change into your desired directory and execute the following command:

```
git clone git@github.com:NetFPGA/NetFPGA-SUME-live.git
```


For more information about git and GitHub in general, please consult GitHub help.

Section III: NetFPGA-SUME Board Kit Content

The NetFPGA-SUME package contains the following:

- NetFPGA-SUME board
- A micro-USB cable
- 4 unique MAC address stickers (one per 10G SFP+ Ethernet port)

Below is an image of the NetFPGA-SUME board, out of the box:



Section IV: NetFPGA-SUME First Power Up

The NetFPGA-SUME board is pre-configured with a manufacturing production test project. The board can be powered up either in a stand alone mode or within a host. The following instructions apply to both modes:

- Plug a PCI-E 2x3/2x4-pin power connector into the 2x4-pin PCI Express Auxiliary Power receptacle (header J14)
- Connect the USB-JTAG port (J16, marked by a "USB JTAG" label) on NetFPGA-SUME board to your PC with the micro-USB cable
- Turn on the power switch (SW1)
- You should see Power LED (LD10) and DONE LED (LD4) turn on immediately. This is an indication of functioning power circuit and FPGA configuration circuit.
- Communicate with the board through hyper-terminal by opening the corresponding serial port with a baud rate of 115200, 8 data bits, 1 stop bit, no parity checking, and no flow control. An operating UART interface also indicates a functioning programming interface. In the following image, minicom is used as the hyper-terminal program in Linux to open the serial port `/dev/ttyUSB1`.

```
File Edit View Search Terminal Help
Welcome to minicom 2.6.2

OPTIONS: I18n
Compiled on Jun 25 2013, 10:33:22.
Port /dev/ttyUSB1, 17:38:22

Press CTRL-A Z for help on special keys

NetFPGA-10G-SUME Production Test

Reg 25: N1_HS = 0xA0

Reg 31: NC1_LS = 0x00
Reg 32: NC1_LS = 0x00
Reg 33: NC1_LS = 0x03

Reg 40: N2_HS_LS = 0xC2
Reg 41: N2_HS_LS = 0x49
Reg 42: N2_HS_LS = 0xEF

Reg 43: N31 = 0x00
Reg 44: N31 = 0x77
Reg 45: N31 = 0x0B
CTRL-A Z for help |115200 8N1 | NOR | Minicom 2.6.2 | VT102 |
```

- The NetFPGA group is still working on an acceptance test project for users to fully verify their boards with minimum amount of external test fixtures. We will update as soon as we finalize the production test project. The new production test project will be available at the NetFPGA-SUME-live repository.

Section V: Known issues and Trouble Shoot

Currently, there are no known issues. We are looking forward to your feedback after you get the board. And we will populate this list as issues are reported along the way.



[Status](#) [API](#) [Training](#) [Shop](#) [Blog](#) [About](#)